



---

# **RZR XP Turbo / XP 1000 Rear Bumper Winch Mount Fairlead Plate - Standard; Wide Spool**

**Polaris RZR XP Turbo / XP 1000 | 2014+**

**Part #: 5401729, 5401739**

**Rev. 091516**

---

**491 W. Garfield Ave., Coldwater, MI 49036 · Phone: 517-278-7768**

**E-mail: [sales-rtpro@sporttruckusainc.com](mailto:sales-rtpro@sporttruckusainc.com)**

---

## **SAFETY WARNING**

RT Pro UTV recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

---

## **WHY BUY RT PRO UTV**

Great off-road driving and racing comes with having the most rugged and durable machine in the pack.

RT Pro UTV performance enhancing products will make your off-road machine stronger, tougher and safer so you can have more fun and less breakdowns.

For over a decade, RT Pro UTV staff have been taking brand new UTVs and driving them to their breaking point. When they bend, break or falter, we take them back to shop and create a fix that stops the problem from happening again.

There is no other company in the industry that puts more thought, engineering and design innovation into their products than we do. Our team is made up of off-road racers, mechanical engineers and talented fabricators who live and breathe all things motorsport. Above all, we share a passion for innovation, quality construction and getting things right.

All of our products are designed for assembly by weekend warriors with normal garage tools and the occasional spot-weld. Assembly directions are complete and thorough.

Remember, when you buy a RT Pro UTV product for your UTV, all of the parts have been designed and manufactured in the United States with U.S. steel and other high quality American components.



<b>RTP5401729</b>		
<b>Part #</b>	<b>Description</b>	<b>QTY</b>
04181	Winch Fairlead STD	1
	3/8-16 x 1" button head screws	2
	3/8-16 nylock nuts	2
	M10 flat washers	4

<b>RTP5401739</b>		
<b>Part #</b>	<b>Description</b>	<b>QTY</b>
04182	Winch Fairlead WIDE	1
	3/8-16 x 1" button head screws	2
	3/8-16 nylock nuts	2
	M10 flat washers	4

## FITMENT NOTES

Kit includes one plate and hardware needed to install fairlead. Fairlead, Winch Mount, Winch and bumper not included.

## SPECIAL TOOLS

N/A

## INSTALLATION TIME

Approximately 20 minutes  
Easy Difficulty

## INSTALLATION INSTRUCTIONS

1. This kit can be installed with the bumper on or off the vehicle.
2. Simply bolt this plate up to your Racer Tech winch mount using the supplied hardware and your own fairlead plate.

**Figure 1**



---

### THANK YOU FOR YOUR BUSINESS!

For questions or additional information feel free to call and ask for tech support or email us through our website at: [rtproutv.com/contact](http://rtproutv.com/contact)



### Show Us Your Ride!

Get a photo of your RT Pro UTV equipped vehicle and send them in for a chance to be featured in our customer gallery!