



---

## **Nerf Bars**

**Polaris RZR 900S / 1000S | All Years**

**Part #: 5401815**

**Rev. 073019**

---

**491 W. Garfield Ave., Coldwater, MI 49036 · Phone: 517-278-7768**

**E-mail: [sales-rtpro@ridefox.com](mailto:sales-rtpro@ridefox.com)**

---

### **SAFETY WARNING**

RT Pro UTV recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

---

### **WHY BUY RT PRO UTV**

Great off-road driving and racing comes with having the most rugged and durable machine in the pack.

RT Pro UTV performance enhancing products will make your off-road machine stronger, tougher and safer so you can have more fun and less breakdowns.

For over a decade, RT Pro UTV staff have been taking brand new UTVs and driving them to their breaking point. When they bend, break or falter, we take them back to shop and create a fix that stops the problem from happening again.

There is no other company in the industry that puts more thought, engineering and design innovation into their products than we do. Our team is made up of off-road racers, mechanical engineers and talented fabricators who live and breathe all things motorsport. Above all, we share a passion for innovation, quality construction and getting things right.

All of our products are designed for assembly by weekend warriors with normal garage tools and the occasional spot-weld. Assembly directions are complete and thorough.

Remember, when you buy a RT Pro UTV product for your UTV, all of the parts have been designed and manufactured in the United States with U.S. steel and other high quality American components.



RTP5401815		
Part #	Description	QTY
04251	Nerf Bar - DRV	1
04252	Nerf Bar - PASS	1
04234	Nerf Bar Retaining Clevis	4
R198	Bolt Pack	1
	<i>3/8" - 16 x 1" Hex Bolt</i>	4
	<i>3/8 Lock Washer</i>	4

## FITMENT NOTES

Drilling hole in frame required

## SPECIAL TOOLS

none

## INSTALLATION TIME

Approximately 2 hours  
Medium Difficulty

## INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean level surface and ensure the vehicle is shifted into park.
2. Remove OEM hardware holding the plastic rockers on the vehicle. Retain mounting hardware
3. Using a 5/8 drill bit, drill out non threaded factory hole through both sides of the frame. This needs to be done on the forward most mounting point as well as the rear upper mounting location. Ensure you drill straight through the frame, keeping the drill bit parallel to the ground. See Figure 1.

**Figure X**



4. Install the nerf bar onto the vehicle by inserting the mounting studs of the front and rear upper mounts through the holes through the frame, They should protrude on the inside of the frame.
5. Install Clevis on the inside frame over the nerf bar studs and fasten using 3/8 hex bolts and Lock washers. See Figure 2. Torque hardware to 30 ft-lbs

*Note: Lower frame skid plate may need to be removed install hardware.*

**Figure 2**



6. Install factory hardware through nerf bar plates and into the stock location.

---

## **THANK YOU FOR YOUR BUSINESS!**

For questions or additional information feel free to call and ask for tech support or email us through our website at: [rtproutv.com/contact](http://rtproutv.com/contact)



### **Show Us Your Ride!**

Get a photo of your RT Pro UTV equipped vehicle and send them in for a chance to be featured in our customer gallery!