



---

## **Sway Bar Brace Kit**

**Polaris RZR XP1000/TURBO | 2014+**

**Part #: 5501011**

**Rev.061218**

---

**491 W. Garfield Ave., Coldwater, MI 49036 · Phone: 517-278-7768**

**E-mail: [sales-rtpro@ridefox.com](mailto:sales-rtpro@ridefox.com)**

---

### **SAFETY WARNING**

RT Pro UTV recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

---

### **WHY BUY RT PRO UTV**

Great off-road driving and racing comes with having the most rugged and durable machine in the pack.

RT Pro UTV performance enhancing products will make your off-road machine stronger, tougher and safer so you can have more fun and less breakdowns.

For over a decade, RT Pro UTV staff have been taking brand new UTVs and driving them to their breaking point. When they bend, break or falter, we take them back to shop and create a fix that stops the problem from happening again.

There is no other company in the industry that puts more thought, engineering and design innovation into their products than we do. Our team is made up of off-road racers, mechanical engineers and talented fabricators who live and breathe all things motorsport. Above all, we share a passion for innovation, quality construction and getting things right.

All of our products are designed for assembly by weekend warriors with normal garage tools and the occasional spot-weld. Assembly directions are complete and thorough.

Remember, when you buy a RT Pro UTV product for your UTV, all of the parts have been designed and manufactured in the United States with U.S. steel and other high quality American components.



RTP5501011		
Part #	Description	QTY
A2053	Sway Brace Assembly - DRV	1
A2054	Sway Brace Assembly - PASS	1
R107	Bolt Pack	1

## FITMENT NOTES

Fits all year and model RZR XP1000 / Turbo

## SPECIAL TOOLS

N/A

## INSTALLATION TIME

Approximately 1 hours  
Easy/Medium Difficulty

## INSTALLATION INSTRUCTIONS

1. Remove upper hardware on the sway bar links and rotate link down in order to slide sway bar through the bracket.
2. Remove hardware on the stock sway bar mount as well as the hardware of the motor mount blocks. You will re-use all the stock bolts in this kit but replace the stock nuts with the provided hardware. Installing one bracket at a time is easier than completely removing sway bar.

- Slide sway bar through bracket and move into position. Note that the sway bar brace is mounted on the bottom of the motor mount , so you DO NOT have to lift the motor in order to install. See Figure 1 and 2

**Figure 1**



**Figure 2**



- Install all hardware loosely to fit, Start with motor mount hardware then install sway bar bracket as shown in figure 3

**Figure 3**



- Once all hardware is started and bracket is in place, tighten sway bar mount hardware to 25 ft lbs, motor mount hardware to 45 ft lbs
- Repeat steps on the opposite side.
- Once both sway bar braces are installed, reinstall the sway bar links to the sway bar and torque hardware to 45 ft lbs.

---

## **THANK YOU FOR YOUR BUSINESS!**

For questions or additional information feel free to call and ask for tech support or email us through our website at: [rtproutv.com/contact](http://rtproutv.com/contact)



### **Show Us Your Ride!**

Get a photo of your RT Pro UTV equipped vehicle and send them in for a chance to be featured in our customer gallery!