



RZR XP 1000 Trailing Arm Brace Kit

Polaris RZR XP 1000 | 2014+

Part #: 5501019

Rev. 090616

491 W. Garfield Ave., Coldwater, MI 49036 · Phone: 517-278-7768

E-mail: sales-rtpro@sporttruckusainc.com

SAFETY WARNING

RT Pro UTV recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

WHY BUY RT PRO UTV

Great off-road driving and racing comes with having the most rugged and durable machine in the pack.

RT Pro UTV performance enhancing products will make your off-road machine stronger, tougher and safer so you can have more fun and less breakdowns.

For over a decade, RT Pro UTV staff have been taking brand new UTVs and driving them to their breaking point. When they bend, break or falter, we take them back to shop and create a fix that stops the problem from happening again.

There is no other company in the industry that puts more thought, engineering and design innovation into their products than we do. Our team is made up of off-road racers, mechanical engineers and talented fabricators who live and breathe all things motorsport. Above all, we share a passion for innovation, quality construction and getting things right.

All of our products are designed for assembly by weekend warriors with normal garage tools and the occasional spot-weld. Assembly directions are complete and thorough.

Remember, when you buy a RT Pro UTV product for your UTV, all of the parts have been designed and manufactured in the United States with U.S. steel and other high quality American components.



RTP5501019

Part #	Description	QTY
04052	Trailing Arm Brace Clevis	2
04053	Trailing Arm Brace Plug	2
04054	Trailing Arm Brace Washer	2

RTP5501019 - Bolt Pack

Part #	Description	QTY
R108	Bolt Pack - Trailing Arm Brace	1
	M12-1.75 x 70mm hex bolt	2
	M12-1.75 nylock nut	2
	M12 flat washer	4
	M10-1.5 x 80mm hex bolt	2
	M10-1.5 nylock nut	2
	M10 flat washer	4

FITMENT NOTES

N/A

SPECIAL TOOLS

N/A

INSTALLATION TIME

Approximately .5 hours
Easy/Medium Difficulty

INSTALLATION INSTRUCTIONS

1. The first step is to jack up the rear of your vehicle and secure with jack stands, as you will be taking bolt out of the front pivot point of your trailing arm. Once you have the vehicle secure and the front bolt is out of your trailing arm, slide the main bracket onto the frame channel and re-install your front trailing arm bolt.
2. Next, ensure the large hole on the bracket and the hole in the frame are concentric so the male plug insert can be mounted through. Install male plug in from the inside of the machine so the washer is mounted on the outside of the machine as illustrated.

Figure 1



Figure 2



3. Once plug is inserted into both sides of the bracket, you may tighten the assembly with the provided hardware *Note that plug will not go completely through both sides of the bracket until it is completely tightened, this extra bit of room allows you to tighten the bracket firmly to the frame rail.
4. Repeat steps to install opposite side.

THANK YOU FOR YOUR BUSINESS!

For questions or additional information feel free to call and ask for tech support or email us through our website at: rtproutv.com/contact



Show Us Your Ride!

Get a photo of your RT Pro UTV equipped vehicle and send them in for a chance to be featured in our customer gallery!