



---

## **Harness Bar**

**Can-am Maverick/Commander | All years**

**Part #: 5802121**

**Rev. 062719**

---

**491 W. Garfield Ave., Coldwater, MI 49036 · Phone: 517-278-7768**

**E-mail: sales-rtpro@ridefox.com**

---

### **SAFETY WARNING**

RT Pro UTV recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

---

### **WHY BUY RT PRO UTV**

Great off-road driving and racing comes with having the most rugged and durable machine in the pack.

RT Pro UTV performance enhancing products will make your off-road machine stronger, tougher and safer so you can have more fun and less breakdowns.

For over a decade, RT Pro UTV staff have been taking brand new UTVs and driving them to their breaking point. When they bend, break or falter, we take them back to shop and create a fix that stops the problem from happening again.

There is no other company in the industry that puts more thought, engineering and design innovation into their products than we do. Our team is made up of off-road racers, mechanical engineers and talented fabricators who live and breathe all things motorsport. Above all, we share a passion for innovation, quality construction and getting things right.

All of our products are designed for assembly by weekend warriors with normal garage tools and the occasional spot-weld. Assembly directions are complete and thorough.

Remember, when you buy a RT Pro UTV product for your UTV, all of the parts have been designed and manufactured in the United States with U.S. steel and other high quality American components.



| RTP5802125 |                     |     |
|------------|---------------------|-----|
| Part #     | Description         | QTY |
| 04434      | Harness Bar, DRV    | 1   |
| 04435      | Harness Bar, PASS   | 1   |
| 04436      | Harness Bar, Center | 1   |
| 04198      | 1-1/2" Flange Clamp | 2   |
| 04282      | Flange Clamp Bar    | 2   |
| 04193      | 2" T-Flange Clamp   | 2   |
| 04437      | Seat Belt Bar Clamp | 2   |

| R167   |                        |     |
|--------|------------------------|-----|
| Part # | Description            | QTY |
| R167   | Bolt Pack              | 1   |
|        | 5/16"-24 x 1-1/2" Bolt | 6   |
|        | 5/16"-24 x 7/8" Bolt   | 12  |
|        | 5/16"-24 Nylock Nut    | 18  |

## FITMENT NOTES

Will not work on X3 or XDS Mavericks

## SPECIAL TOOLS

NONE

## INSTALLATION TIME

Approximately 1 hours  
Easy Difficulty

## INSTALLATION INSTRUCTIONS

1. Park vehicle on clean level surface and make sure the vehicle is shifted into park.
2. Slide both 04434 and 04435 onto the center bar (04436) Position on bars behind seat and telescope outwards so that the clamps capture the lower roll cage bar. (See Figure 1)ach outer harness bars with the outer Flange Clamp (04193), with the Flange Clamp bar (04282) sandwiched between them. Fasten using 5/16-24 x 1-1/2" hardware. Leave hardware loose.

3. Attach the Seat Belt Bar Clamp (04437) and 1-1/2" Flange Clamp (04198) to the harness bar. These should cover the section of the harness bar that telescopes. This should sit directly behind the seats as shown in Figure 1.

**Figure 1**



4. Once seat belt brackets are in place tighten all hardware. Torque 5/16 hardware 27 ft-lbs.

---

## **THANK YOU FOR YOUR BUSINESS!**

For questions or additional information feel free to call and ask for tech support or email us through our website at: [rtproutv.com/contact](http://rtproutv.com/contact)



### **Show Us Your Ride!**

Get a photo of your RT Pro UTV equipped vehicle and send them in for a chance to be featured in our customer gallery!