

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039 CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

## INSTALLATION INSTRUCTIONS

# PYRO FRONT BUMPER SKIDPLATE

JK19001

FOR USE WITH ALL JK AND JKU MODELS FROM 2007-2018





#### WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART#	Qty	DESCRIPTION
06048	1	BUMPER - JK FRONT - PYRO
CWLU30010	1	DECAL: CRAWLTEK GEARSHIFT 3.5" X 3.5"
CWLU30020	1	DECAL: CRAWLTEK EYES 6" X 2"
CWLU30030	1	DECAL: CRAWLTEK JAX 3.75" X 2.8"
	6	5/16"-18 X 1" ZINC STEEL BUTTON SOCKET CAP SCREW
	6	5/16"-18 ZINC SERRATED FLANGE NUT
	2	5/16"-18 PANEL RANGE: .025"150" CENTER 27/32" EXTRUDED U NUT

### TOOLS REQUIRED

SAFETY GLASSES RECIPROCATING SAW (OPTIONAL) 1/2" SOCKET OR WRENCH 3/16" ALLEN HEAD SOCKET SMALL HAMMER

#### PRE-INSTALLATION NOTES

1. 2007-2010 VEHICLES HAVE A CRASH BAR THAT EXTENDS OUT FURTHER AND WILL NEED TO BE TRIMMED FLUSH WITH FRAME RAILS.

#### INSTALLATION OF THEPYRO FRONT BUMPER SKID PLATE

#### **STEP 1 (OPTIONAL):**

2007-2010 VEHICLES WILL NEED TO TRIM THE CRASH BAR ENDS AS THEY PROTRUDE FURTHER THAN NEWER MODELS.

#### STEP 2:

INSTALL 2 U NUTS INTO BOTTOM OF CRASH BAR (YEAR DEPENDENT, LOOSELY INSTALL HARDWARE.

#### STEP 3:

SIDE BOLTS, LINE UP THE HOLES WITH HOLES THAT MATCH ON THE FRAME. SLIDE 5/16" NUT INTO FRAME POCKET WITH WRENCH, ATTACH BOLTS

#### STEP 4:

TIGHTEN ALL HARDWARE, GO WHEEL.







### YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

Be sure to show off your jeep to the rest of the CrawlTek Revolution online.

Find us on facebook and instagram to keep up on new products, upcoming events and more action.

Tag us @crawltek for a chance to get featured



