



XP1000 Rear Sway Bar Links

Polaris RZR | All Years

Part #: 5601709

Rev. 103019

491 W. Garfield Ave., Coldwater, MI 49036 · Phone: 517-278-7768

E-mail: sales-rtpro@ridefox.com

SAFETY WARNING

RT Pro UTV recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

WHY BUY RT PRO UTV

Great off-road driving and racing comes with having the most rugged and durable machine in the pack.

RT Pro UTV performance enhancing products will make your off-road machine stronger, tougher and safer so you can have more fun and less breakdowns.

For over a decade, RT Pro UTV staff have been taking brand new UTVs and driving them to their breaking point. When they bend, break or falter, we take them back to shop and create a fix that stops the problem from happening again.

There is no other company in the industry that puts more thought, engineering and design innovation into their products than we do. Our team is made up of off-road racers, mechanical engineers and talented fabricators who live and breathe all things motorsport. Above all, we share a passion for innovation, quality construction and getting things right.

All of our products are designed for assembly by weekend warriors with normal garage tools and the occasional spot-weld. Assembly directions are complete and thorough.

Remember, when you buy a RT Pro UTV product for your UTV, all of the parts have been designed and manufactured in the United States with U.S. steel and other high quality American components.



RTP5601709		
Part #	Description	QTY
OSC-XP1-SBLINK	Rear Sway Bar Link Kit	1

FITMENT NOTES

None

SPECIAL TOOLS

None

INSTALLATION TIME

Approximately 1 hours
Easy Difficulty

INSTALLATION INSTRUCTIONS

1. Park vehicle on a clean level surface and ensure the vehicle is in shifted into park.
2. Remove stock sway bar links from trailing arm and sway bar. Retain factory hardware.
3. Insert included misalignments in both sides of the spherical bearings.
4. Install sway bar links on sway bar and then on the trailing arm using factory hardware. Torque bolts to 40 ft-lbs. See Figure 1.

Figure 1



THANK YOU FOR YOUR BUSINESS!

For questions or additional information feel free to call and ask for tech support or email us through our website at: rtproutv.com/contact



Show Us Your Ride!

Get a photo of your RT Pro UTV equipped vehicle and send them in for a chance to be featured in our customer gallery!